

WHITE SHARK



BT 5.3 / WIRELESS
USB - TRIPLE MODE
LUCAN
BT/WIRELESS GAMING MOUSE

User manual

Special On/Off Function:

- Slide the switch left to BT mode.
- Slide the switch right to 2.4G mode.
- The middle switch is for OFF.

EN-1

Connection Methods:

1. Wired Connection:

- Connect the mouse's USB cable to the computer's USB port.
- Plug the Type-C port into the mouse for direct use.

Note: No matter the mode switch is in any position, after put in the TYPE-C cable, it automatically switches to the wired mode.

2. 2.4G Wireless Connection:

- Insert the 2.4G receiver into the computer.
- Set the mode switch to 2.4G.

Note:

- 2.4G pairing only supports PC software pairing.
- The 2.4G pairing process lasts for 30 seconds.

3. Bluetooth (BT) Connection:

- Switch to BT mode.
- Enable Bluetooth discovery on your device and select "LUCAN".

BT Pairing:

In BT mode, press and hold the left + middle + right keys simultaneously until the indicator light will rapidly flash blue, select "LUCAN" to connect. After successful connection, the indicator light will remain blue and flash for 3 seconds, then go out.

Note:

The Bluetooth pairing takes 120 seconds.

EN-2

DPI setting and Indicator:

1. DPI levels:

800 red - 1600 green (default) - 2400 blue - 3200 cyan - 6400 yellow - 12000 purple

Note:

DPI levels can be adjusted by the software.

Battery Management:

- In wireless mode, a low battery prompt will be triggered when the battery voltage drops below 3.3V. If the battery voltage falls below 3.1V, the system will enter a low battery shutdown protection state.
- Low battery: The indicator light flash red, the mouse needs to be charged.
- During charging, the charging voltage is 5V and the indicator light shows red flashing. The maximum charging current is less than 200mA.
- Charging Status: around 1.5~2 hours for full charge. Once fully charged, the indicator light is on green.

Note: It is prohibited to use high-power mobile phone fast charging to charge the mouse. This may cause the charging IC to burn out. It is recommended to use the included charging cable and an ordinary charging head with a power of 5A or below to charge the product.

Sleep Mode:

- After 1 minute of inactivity, the mouse enters sleep mode.
- Wake up: Move the mouse.

EN-3

Warnings and Safeguards

1. Don't expose these products to humidity, water, or any other liquid.
2. Don't expose to extremely hot or extremely cold temperatures/conditions.
3. Don't operate if the unit has become wet or moist. The unit is not waterproof or water-resistant.
4. Don't damage the USB power cord by bending, twisting pulling, or heating it.
5. Don't use harsh chemicals (such as benzene, thinners, etc.) or detergents to clean your products.
6. Never attempt to disassemble or modify your products in any way or use with incompatible computers. Doing so violates any warranty in place and may cause permanent damage to the unit.

System Requirements

Win XP / Win 7 / Win 8 / Win 10 / Win 11 / or above operating system.

WHITE SHARK

EC REP

ŠMIT ELECTRONIC d.o.o.
Metanska 1, KUTINA, CROATIA
Tel. +38544680704
info@smit-electronic.hr

Product name: BT / 2.4GHz Wireless Mouse
Model: LUCAN
Battery capacity: 300 mAh
Rated voltage: 3.7V
Rated current: 8-13 mA
S/N Production batch
number: WGM5022012026



Manufacturer: SBOX TECHNOLOGY LTD, FLAT 906, 9/F.,
WORKINGPORT COMM. BLDG., 3 HAUFHOOK ST., TSIM SHA TSUI, KOWLOON, HONG
KONG, hello@whiteshark.gg, www.whiteshark.gg Made in China.

EN-4

WHITE SHARK



WHITE SHARK



BT 5.3 / WIRELESS
USB - TRIPLE MODE
LUCAN
BT/WIRELESS GAMING MOUSE

Upute

Special On/Off Function:

- Pomaknite prekidač ulijevo na BT način rada.
- Pomaknite prekidač udesno na 2.4G način rada.
- Srednji položaj prekidača služi za OFF (isključeno).

HR-1

Načini povezivanja:

1. Žično povezivanje:

- Spojite USB kabel miša u USB priključak računala.
- Umetnite Type-C priključak u miš za izravno korištenje.

Napomena: Bez obzira u kojem se položaju nalazi prekidač načina rada, nakon umetanja TYPE-C kabela miš se automatski prebacuje u žični način rada.

2. 2.4G bežično povezivanje:

- Umetnite 2.4G prijemnik u računalo.
- Postavite prekidač načina rada na 2.4G.

Napomena:

- 2.4G uparivanje podržava samo uparivanje putem PC softvera.
- Postupak 2.4G uparivanja traje 30 sekundi.

3. Bluetooth (BT) povezivanje:

- Prebacite na BT način rada.
- Uključite Bluetooth pretraživanje na svom uređaju i odaberite „LUCAN“.

BT uparivanje:

U BT načinu rada pritisnite i držite lijevu + srednju + desnu tipku istovremeno dok indikatorsko svjetlo ne počne brzo treperiti plavom bojom, zatim odaberite „LUCAN“ za povezivanje. Nakon uspješnog povezivanja, indikatorsko svjetlo ostat će plavo i treperiti 3 sekunde, a zatim će se ugasi.

Napomena:

Bluetooth uparivanje traje 120 sekundi.

HR-2

Postavke DPI-ja i indikator:

1. Razine DPI-ja:

800 crvena / 1600 zelena (zadano) / 2400 plava / 3200 cijan / 6400 žuta / 12000 ljubičasta

Napomena:

Razine DPI-ja mogu se podešavati putem softvera.

Upravljanje baterijom:

- U bežičnom načinu rada, upozorenje na nisku razinu baterije aktivira se kada napon baterije padne ispod 3.3 V. Ako napon baterije padne ispod 3.1 V, sustav će ući u zaštitno stanje isključivanja zbog niske baterije.
- Niska razina baterije: indikatorsko svjetlo treperi crveno, miš je potrebno napuniti.
- Tijekom punjenja, napon punjenja iznosi 5 V, a indikatorsko svjetlo pokazuje crveno treperenje. Maksimalna struja punjenja manja je od 200 mA.
- Status punjenja: približno 1.5 – 2 sata za potpuno punjenje. Nakon potpunog punjenja, indikatorsko svjetlo svijetli zeleno.

Napomena: Zabranjeno je koristiti brzo punjenje mobilnih telefona velike snage za punjenje miša. To može uzrokovati izgaranje IC-a za punjenje. Preporučuje se koristiti priloženi kabel za punjenje i obični punjač snage 5 A ili manje za punjenje proizvoda.

Način mirovanja (Sleep Mode):

- Nakon 1 minute neaktivnosti, miš ulazi u način mirovanja.
- Buđenje: pomaknite miš.

HR-3

Upozorenja i mjere zaštite:

1. Ne izlažite proizvod vlazi, vodi ili bilo kojoj drugoj tekućini.
2. Ne izlažite proizvod ekstremno visokim ili ekstremno niskim temperaturama/uvjetima.
3. Ne koristite proizvod ako je postao mokar ili vlažan. Proizvod nije vodootporan niti otporan na vlagu.
4. Ne oštećujte USB kabel savijanjem, uvijanjem, povlačenjem ili zagrijavanjem.
5. Ne koristite jake kemikalije (kao što su benzen, razrjeđivači itd.) ili deterdžente za čišćenje proizvoda.
6. Nikada ne pokušavajte rastavljati ili modificirati proizvod niti ga koristiti s nekompatibilnim računalima. Time se krši jamstvo i može doći do trajnog oštećenja uređaja.

Zahtjevi sustava:

Operativni sustavi Win XP / Win 7 / Win 8 / Win 10 / Win 11 ili noviji.

WHITE SHARK

EC REP

ŠMIT ELECTRONIC d.o.o.
Metanska 1, KUTINA, CROATIA
Tel. +38544680704
info@smit-electronic.hr

Product name: BT / 2.4GHz Wireless Mouse
Model: LUCAN
Battery capacity: 300 mAh
Rated voltage: 3.7V
Rated current: 8-13 mA
S/N Production batch
number: WGM5022012026



Manufacturer: SBOX TECHNOLOGY LTD, FLAT 906, 9/F.,
WORKINGPORT COMM. BLDG., 3 HAUFHOOK ST., TSIM SHA TSUI, KOWLOON, HONG
KONG, hello@whiteshark.gg, www.whiteshark.gg Made in China.

HR-4

WARRANTY CARD / JAMSTVENI LIST

ITEM/MODEL: Naziv/model proizvoda:	
RECEIPT NO. / DATE OF PURCHASE: Broj i datum računa:	
SELLING SPOT (COMPANY): Prodajno mjesto:	
THE CUSTOMER: Kupac:	
WARRANTY PERIOD (MONTHS): Jamstveni rok (Mjeseci):	36
SIGNATURE / STAMP: Potpis i pečat:	

All White Shark products are examined and tested after each stage of the production process and have all the required certificates (EMC, CE, ...). The products are subject to the following warranty conditions: • The warranty period for White Shark products is 36 months (on batteries 6 months) and begins on the day of being sold in the store • The warranty can only be claimed upon presentation of the original purchase invoice and a filed warranty paper with a stamp from the store it was bought at, and if the product has original packaging and all components and equipment • All malfunctioning of the product resulting from factory defects, that occur during the warranty period, and in the normal use of the product in compliance with all instructions will be removed. This warranty covers only defects in material and production. • If the product malfunctions during the warranty period, your White Shark distributor will give you the product (after which is checked by a professional) repaired or replaced • If the repair at the authorized service center is not completed within 30 days of being received at the service center, we will replace the product with a new one. If the repair during the warranty period lasts longer than 15 days, the warranty period is extended by as many days as the repair lasted. • If the device needs to be repaired within the warranty period, contact the store where you bought the product. If the product has to be sent to an authorized service center or general distributor, please send the product (with all parts and accessories) in the original packaging and with all the necessary documents (invoice, warranty card, etc.). The product can be repaired only in the authorized service center of the importer. The costs of shipping the product to the service center are funded by the customer. Possible damage to the product that can occur during transport is at the expense and risk of the buyer. Sending the product from the service center to the customer is funded by the service technician/the importer. This warranty does NOT cover: • Damage or malfunctions that would occur as a result of incorrect connection, incorrect polarization, incorrect battery placement, etc. • Defects caused by improper handling of products, use of parts or equipment that is not prescribed by our specifications, unauthorized product modification, and defects mechanical damage to the product • Defects that can occur due to product fall, use of force, natural disasters (flood, fire, thunder, earthquake, ...), due to battery leakage, due to unstable 220V voltage, frequent variations and/or power outages, etc. • Damage caused during transport to the customer • Products that have been opened or repaired by an unauthorized person • Parts that are considered consumables such as batteries, etc.

Svi White Shark proizvodi su provjereni i testirani nakon svake faze proizvodnog procesa te imaju sve potrebne certifikate (EMC, CE, ...) te podliježu sljedećim jamstvenim uvjetima: • Jamstveni rok na White Shark proizvode je 36 mjeseci (na baterije 6 m.) i počinje teći danom prodaje u trgovini • Jamstvo se može ostvariti samo uz predložene originalnog računa o kupnji i uredno popunjenoj jamstvenoj listi, sa žigom trgovine, te ako proizvod ima originalnu ambalažu i sve sastavne dijelove i opremu. • Svi nedostaci i kvarovi koji su posljedica tvorničkih grešaka i koji su nastali u jamstvenom roku i pri normalnoj uporabi proizvoda i pri poštivanju svih naputaka će biti otklonjeni. Ovo jamstvo obuhvaća samo greške nastale u materijalu i izradi. • Ako se proizvod pokvari tijekom jamstvenog roka, Vaš White Shark distributer će vam proizvod popraviti ili zamijeniti nakon što ga provjeri stručna osoba • Ako popravak u ovlaštenom servisu nije izvršen u roku 30 dana od primitka u servis, proizvod ćemo zamijeniti novim. U slučaju da popravak u jamstvenom roku traje duže od 15 dana, jamstveni rok se produžuje za onoliko dana koliko je popravak trajao. • Ako se ukaže potreba popravka uređaja u jamstvenom roku, kontaktirajte trgovinu u kojoj ste proizvod i kupili. Ako proizvod treba poslati ovlaštenom servisu ili generalnom distributeru, molimo Vas da kompletan proizvod (sa svim dijelovima i opremom) bude zapakiran u originalnu ambalažu te da priložite sve potrebne dokumente (račun i ovjereni jamstveni list). Popravak aparata vrši se isključivo u ovlaštenom servisu uzvornika. Troškove prijevoza proizvoda na servis snosi kupac. • Kupac preuzima rizik za moguća oštećenja tijekom prijevoza. Slanje proizvoda od servisa do kupca snosi servise tj. uzvornik. Ovo jamstvo NE obuhvaća: • Oštećenja ili kvarove koji su nastali kao posljedica nepravilnog priključivanja, krive polarizacije, pogrešnog stavljanja baterija i sl. • Kvarove nastale zbog nepropisnog rukovanja proizvodom, korištenja dijelova ili opreme koja nije propisana našim specifikacijama, neovlašteno modificiranje proizvoda ili kvarove nastale mehaničkim oštećenjem proizvoda • Kvarove koji mogu nastati uslijed pada proizvoda, uporabe sile, više sile tj. elementarnih nepogoda (poplava, požar, grom, potres, ...) uslijed curenja baterije, uslijed nestabilnog 220V napona, čestih varijacija i/ili nestanaka struje i sl. • Oštećenja nastala pri prijevozu do kupca • Proizvod koji je otvoren i/ili popravljan od strane neovlaštene osobe • Dijelove koji se smatraju potrošnim kao što su baterije i sl.

WHITE SHARK