



NUNCHAKU

MECHANICAL RGB GAMING KEYBOARD

User manual

Specifications and Features:

- * Buttons: Compact 68 keys - Gradient keycaps
- * Switches: Hot Swap dust-proof mechanical blue or red
- * Anti-ghosting: Full keys
- * Polling rate: 1000 Hz
- * Full key RGB LED backlight
- * Dimensions: 310 mm x 101 mm x 42 mm
- * Material: ABS plastic
- * Key life: over 50 million times
- * Weight: 550 g ±10g
- * With extra 4pcs White Shark customized switches
- * 60% ultra-compact layout
- * Solid Type-C wired connection
- * Hot-Swap dust-proof mechanical red switches for silent typing
- * 18 LED effects with adjustable light brightness and running speed
- * 1.8 m braided detachable cable
- * Available software on www.whiteshark.gg

EN-1

LED Indicator Description:

Caps Lock: white LED on Caps Lock keycap when single press Caps Lock or Fn + Caps Lock
 Windows Lock: white LED on Windows keycap when single press Fn + Caps Lock

FN combination function

1. Multimedia functions:

For example, if single press ESC, it's ESC; if press FN + ESC, it's ` ;
 If press FN + Shift + ESC, it's ~

If single press Q, it's Q; if press FN+Q, it's My Computer


Single press	FN +	Single press	FN +	Single press	FN +
ESC	`	Q	My Computer	::	Home
1	F1	W	Homepage	""	End
2	F2	E	Email	,<	PRTSC
3	F3	R	Media player	,>	Scroll Lock
4	F4	T	previous track	/?	Pause
5	F5	Y	next track		
6	F6	U	Play/Pause		
7	F7	I	Stop		
8	F8	O	Volume +		
9	F9	P	Volume -		
0	F10	[[Mute		
_	F11]]	Calculator		
=+	F12		N/A		

EN-2

2. Combination function

FN +		remarks
INS	Switch backlight mode	18 light modes plus light off
DEL	Light color switch	Light effect cycle switching (red, orange, yellow, green, cyan, blue purple, white multicolor)
UP	Light brightness +	0%-25%-50%-75%-100%, and the indicator flashes 3 times when it is adjusted to the brightest.
DOWN	Light brightness -	100% -75% -50% -25% -0%, when adjusted to the darkest, the indicator light flashes for 3 times.
LEFT	Light speed -	There are 5 adjustable speeds in total. When the speed is adjusted to the slowest, the indicator light will flash for 3 times.
RIGHT	Light speed +	There are 5 adjustable speeds in total. When the fastest speed is adjusted, the indicator light will flash for 3 times.
PU	Light running from left to right	
PD	Light running from right to left	
WIN_L	WIN lock	White led indicator
SPACE	reset	FN+SPACE: Long press for 3 seconds to restore factory Settings, and backlight flashes three times

EN-3



NUNCHAKU

MECHANICAL RGB GAMING KEYBOARD

Upute

Karakteristike i značajke:

- * Broj tipki: Kompakt 68 tipki - Gradient tipke
- * Prekidači: Izmjenjivi meh. plavi ili crveni otporni na prašinu
- * Anti-ghosting: Sve tipke
- * Frekvencija uzorkovanja: 1000 Hz
- * Pozadinsko osvjetljenje: RGB
- * Dimenzije: 310 mm x 101 mm x 42 mm
- * Materijal: ABS plastika
- * Životni vijek tipki: preko 50 mil. pritisaka
- * Težina: 550 g ±10g
- * 4 dodatna White Shark switcha
- * 60% ultra-kompakt layout
- * Type-C sučelje
- * Hot-Swap Mehanički crveni prekidači otporni na prašinu za tiho tipkanje
- * 18 LED efekata s podesivom razinom jačine i brzinom izmjene efekta
- * Odvojivi pleteni kabel od 1,8 m
- * Softver dostupan na www.whiteshark.gg

HR-1

Opis LED indikatora:

Caps Lock: bijela LED lampica na tipki Caps Lock svijetli kada se jednom pritisne tipka Caps Lock ili Fn + Caps Lock.
 Zaključavanje Windows tipke: bijela LED lampica na tipki Windows svijetli kada se jednom pritisne Fn + Caps Lock.

Funkcije kombinacija s tipkom FN

1. Multimediajske funkcije:

Na primjer ako se jednom pritisne ESC to je ESC
 Ako se pritisne FN + ESC to je `
 Ako se pritisne FN + Shift + ESC to je ~

Ako se jednom pritisne Q to je Q, Ako se pritisne FN + Q to je My Computer

Pritisak na tipku	FN +	Pritisak na tipku	FN +	Pritisak na tipku	FN +
ESC	`	Q	My Computer	::	Home
1	F1	W	Početna stranica	""	End
2	F2	E	Email	,<	PRTSC
3	F3	R	Media player	,>	Scroll Lock
4	F4	T	Prethodna pjesma	/?	Pauza
5	F5	Y	Sjedeća pjesma		
6	F6	U	Pokreni/Pauza		
7	F7	I	Stop		
8	F8	O	Pojačavanje		
9	F9	P	Stišavanje		
0	F10	[[Nečujno		
_	F11]]	Kalkulator		
=+	F12		N/A		

HR-2

2. Kombinacije tipki za kontrolu osvjetljenja

FN +		Napomene
INS	Prebacivanje načina pozadinskog osvjetljenja	18 načina osvjetljenja plus isključeno svjetlo
DEL	Prebacivanje boje svjetla	Izmjena svjetlosnih efekata (crvena, narančasta, žuta, zelena, cyan plava, bijela, višebojna)
UP	Povećanje svjetline +	0%-25%-50%-75%-100%, indikator zatreperi 3 puta kada je podešeno na najjače osvjetljenje
DOWN	Smanjenje svjetline -	100% -75% -50% -25% -0%, kada je podešeno na najtamnije, indikator zatreperi 3 puta
LEFT	Smanjenje brzine svjetlosnih efekata -	Ukupno 5 podesivih brzina; kada je podešeno na najsporije, indikator zatreperi 3 puta
RIGHT	Povećanje brzine svjetlosnih efekata +	Ukupno 5 podesivih brzina; kada je podešeno na najbrže, indikator zatreperi 3 puta
PU	Svjetlosni efekt – "trčanje" svjetla s lijeva na desno	
PD	Svjetlosni efekt – "trčanje" svjetla s desna na lijevo	
WIN_L	Zaklj. WIN tipke	Bijeli LED indikator
SPACE	reset	FN+SPACE: Dugi pritisak od 3 sekunde vraća tvorničke postavke; Pozadinsko svjetlo zatreperi tri puta

HR-3

WARRANTY CARD / JAMSTVENI LIST

ITEM/MODEL: Naziv/model proizvoda:	
RECEIPT NO. / DATE OF PURCHASE: Broj i datum računa:	
SELLING SPOT (COMPANY): Prodajno mjesto:	
THE CUSTOMER: Kupac:	
WARRANTY PERIOD (MONTHS): Jamstveni rok (Mjeseci):	36 SIGNATURE / STAMP: Potpis i pečat:

All White Shark products are examined and tested after each stage of the production process and have all the required certificates (EMC, CE, ...). The products are subject to the following warranty conditions: - The warranty period for White Shark products is 36 months (on batteries 6 months) and begins on the day of being sold in the store. - The warranty can only be claimed upon presentation of the original purchase invoice and a filed warranty paper with a stamp from the store it was bought at, and if the product has original packaging and all components and equipment. - All malfunctioning of the product resulting from factory defects, that occur during the warranty period, and in the normal use of the product in compliance with all instructions will be removed. This warranty covers only defects in material and production. - If the product malfunctions during the warranty period, your White Shark distributor will give you the product (after which is checked by a professional) repaired or replaced. - If the repair at the authorized service center is not completed within 30 days of being received at the service center, we will replace the product with a new one. If the repair during the warranty period lasts longer than 15 days, the warranty period is extended by as many days as the repair lasted. - If the device needs to be repaired within the warranty period, contact the store where you bought the product. If the product has to be sent to an authorized service center or general distributor, please send the product (with all parts and accessories) in the original packaging and with all the necessary documents (invoice, warranty card, etc.). The product can be repaired only in the authorized service center of the importer. The costs of shipping the product to the service center are funded by the customer. Possible damage to the product that can occur during transport is at the expense and risk of the buyer. Sending the product from the service center to the customer is funded by the service technician/the importer. This warranty does NOT cover: - Damage or malfunctions that would occur as a result of incorrect connection, incorrect polarization, incorrect battery placement, etc. - Defects caused by improper handling of products, use of parts or equipment that is not prescribed by our specifications, unauthorized product modification, and defects mechanical damage to the product. - Defects that can occur due to product fall, use of force, natural disasters (flood, fire, thunder, earthquake, ...), due to battery leakage, due to unstable 220V voltage, frequent variations and/or power outages, etc. - Damage caused during transport to the customer. - Products that have been opened or repaired by an unauthorized person. - Parts that are considered consumables such as batteries, etc.

Svi White Shark proizvodi su provjereni i testirani nakon svake faze proizvodnog procesa te imaju sve potrebne certifikate (EMC, CE, ...) te podliježu sljedećim jamstvenim uvjetima: - Jamstveni rok na White Shark proizvode je 36 mjeseci (na baterije 6 m.) i počinje teći danom prodaje u trgovini. - Jamstvo se može ostvariti samo uz predocenje originalnog računa o kupnji i uredno popunjenog jamstvenog lista sa žigom trgovine, te ako proizvod ima originalnu ambalažu i sve sastavne dijelove i opremu. - Svi nedostaci i kvarovi koji su posljedica tvorničkih grešaka i koji su nastali u jamstvenom roku i pri normalnoj uporabi proizvoda i pri poštivanju svih naputaka će biti otklonjeni. Ovo jamstvo obuhvaća samo greške nastale u materijalu i izradi. - Ako se proizvod pokvari tijekom jamstvenog roka, Vaš White Shark distributer će Vam proizvod popraviti ili zamijeniti nakon što ga provjeri stručna osoba. - Ako popravak u ovlaštenom servisu nije izvršen u roku 30 dana od primitka u servis, proizvod ćemo zamijeniti novim. U slučaju da popravak u jamstvenom roku traje duže od 15 dana, jamstveni rok se produžuje za onoliko dana koliko je popravak trajao. - Ako se ukaze potreba popravka uređaja u jamstvenom roku, kontaktirajte trgovinu u kojoj ste proizvod kupili. Ako proizvod treba poslati ovlaštenom servisu ili generalnom distributeru, molimo Vas da kompletan proizvod (sa svim dijelovima i opremom) bude zapakiran u originalnu ambalažu te da priložite sve potrebne dokumente (račun i ovjereni jamstveni list). Popravak aparata vrši se isključivo u ovlaštenom servisu uvoznika. Troškove prijevoza proizvoda na servis snosi kupac. - Kupac preuzima rizik za moguća oštećenja tijekom prijevoza. Slanje proizvoda od servisa do kupca snosi serviser tj. uvoznik. Ovo jamstvo NE obuhvaća: - Oštećenja ili kvarove koji su nastali kao posljedica nepravilnog priključivanja, krive polarizacije, pogrešnog stavljanja baterija i sl. - Kvarove nastale zbog nepropisanog rukovanja proizvodom, korištenja dijelova ili opreme koja nije propisana našim specifikacijama, neovlaštenog modificiranja proizvoda te kvarove nastale mehaničkim oštećenjem proizvoda. - Kvarove koji mogu nastati uslijed pada proizvoda, uporabe sile, više sile tj. elementarnih nepogoda (poplava, požar, grom, potres, ...), uslijed curenja baterije, uslijed nestabilnog 220V napona, čestih varijacija i/ili nestanka struje i sl. - Oštećenja nastala pri prijavi do kupca. - Proizvod koji je otvoren i/ili popravljan od strane neovlaštene osobe. - Dijelove koji se smatraju potrošnim kao što su baterije i sl.

