

## UPUTE



1. LED Indikator: Bijeli LED - 2.4G način rada  
Plavi LED - BT način rada
2. + tipka  
\* Jedan klik: Pojačavanje zvuka  
\* Dugi pritisak: pojačavanje do Max. glasnoće  
\* Dupli klik: sljedeća pjesma
3. Tipka za uključivanje/isključivanje.  
\* Dugi pritisak 3 sekunde: on/off  
\* Dupli klik: Prebacivanje Gaming mode / Music mode  
\* Jedan klik (dok se sluša glazba): Reprodukcija/Pauza  
\* Jedan klik (za vrijeme dolaznog poziva): javljanje na poziv, jedan klik za prekid poziva  
\* Dugi pritisak 3 sekunde (za vrijeme dolaznog poziva): Odbijanje poziva  
\* Trostruki klik: Siri glasovni asistent
4. - tipka.  
\* Jedan klik: Stišavanje zvuka  
\* Dugi pritisak: stišavanje do min. glasnoće  
\* Dupli klik: prethodna pjesma
5. Prekidač načina rada.  
\* Gore: 2.4G način.  
\* Dolje: BT način.

6. Type-C sučelje za punjenje i 3.5mm Audio sučelje.
7. Ugrađeni mikروفon
8. Odvojivi mikروفon
9. MIC tipka  
Jedan klik: Uključivanje/isključivanje mikrofona  
Dupli klik: Prisilno otpajanje veze / ponovno uparivanje

### Glasovne poruke:

- \* Glasovna obavijest o praznoj bateriji aktivirat će se 20 minuta prije isključivanja slušalice. Oglasit će se 3 zvučna signala svakih 5 minuta, tako da će zadnjih 20 minuta biti 4 podsjetnika, \* Jedan zvučni signal: mikروفon isključen
- \* Dva zvučna signala: mikروفon uključen, \* Jedan zvučni signal: Max. glasnoća
- \* Ženski glas za uključivanje/isključivanje slušalice


### Napomene:

Kako bi slušalice nastavile raditi bežično tijekom punjenja, korisnici prvo moraju priključiti USB kabel na izvor napajanja, a zatim ga priključiti na Type-C sučelje slušalice. U suprotnom, ako prvo priključite Type-C na slušalice, slušalice će se ugasiti i prebaciti se na žičani način rada.

## USER MANUAL



1. LED Indicator: White LED - 2.4G Mode  
Blue LED - BT Mode
2. + key  
\* Single click: Volume +  
\* Long press: until to Max. Volume  
\* Double click: next song
3. Power key.  
\* Long press 3 Seconds: Power on/off  
\* Double click: Switch between Gaming mode and Music mode  
\* Single click(when playing music): Play/Pause  
\* Single click(when there is an incoming call): pick up the call, single click again to hang up the call  
\* Long press 3 Seconds(when there is an incoming call): Reject the call  
\* Triple click: Siri Voice assistant
4. - key.  
\* Single click: Volume -  
\* Long press: until to min. volume  
\* Double click: previous song
5. Mode switch.  
\* Up: 2.4G Mode.  
\* Down: BT Mode.



6. Type-C Charging port and 3.5mm Audio port.
7. Built-in microphone pick up port
8. Detachable microphone
9. MIC Key  
Single click: Turn on/off Microphone  
Double click: Force to disconnect/re-plug

### Prompt voice:

- \* Low battery voice prompt will be activated 20 minutes before headset power off. It will be 3 beeps every 5 minutes, so 20 minutes will have 4 times reminder, \* One beep: microphone mute
- \* Two beeps: microphone on, \* One beep: max. volume
- \* female voice: power on/off

### Remarks:

To support headset is working while charging feature, users must plug USB cable to source power firstly, then plug headset Type-C to headset. Otherwise if plug Type-C to headset firstly, headset will power off and switch to wired mode automatically.