

Please make sure to turn on "on/off" switch at the back of the keyboard before using this keyboard.

Default	Function	Description
FN+ESC	~	
FN+1	F1	
FN+2	F2	
FN+3	F3	
FN+4	F4	
FN+5	F5	
FN+6	F6	
FN+7	F7	
FN+8	F8	
FN+9	F9	
FN+0	F10	
FN+ _	F11	
FN+ =+	F12	
FN+backspace	DEL	
FN+CTRL_L	Switch ESC to += functions to ~ to F12	
FN+~	ESC	
FN+1	music	
FN+2	Volume -	
FN+3	Volume +	
FN+4	Mute	
FN+5	Stop	
FN+6	Previous track	
FN+7	Play/Pause	
FN+8	Next track	
FN+9	Email	
FN+0	Homepage	
FN+_	My computer	
FN+=	Calculator	
FN+U	prtsc	
FN+I	scrik	
FN+O	pause	
FN+J	ins	
FN+K	home	
FN+L	pgup	
FN+M	del	
FN+<	end	
FN+>	pgdn	
FN+Z	For Windows system	
FN+X	For MAC system	
FN+TAB	Switch Backlight Color	Under single light mode, total 8 different colors to switch
FN+_	Switch light effect	Light effect cycle adjustment, 22 kinds of light modes
FN+↓	Brightness-	0%-20%-40%-60%-80%-100%
FN+↑	Brightness +	0%-20%-40%-60%-80%-100%
FN+→	Lower speed	
FN+←	Faster speed	
FN+R	Switch to BT device 1(BT3.0&5.0)	Short press, switch to BT, long press for 3s, delete pairing info and start to connect new BT device.
FN+T	Switch to BT device 2(BT3.0&5.0)	The key led will be flash if disconnected, stop flashing after connected.
FN+Y	Switch to BT device 3(BT3.0&5.0)	
FN+Q	Switch to 2.4GHZ Mode	The nano receiver needs to be plugged firstly, Long press 3S, enter pairing state and key LED flash, and after connected, stop flash
FN+E	Switch to Wired mode	
FN+WIN_L	Lock windows	Windows and APP buttons no function
FN+ENTER	KB all lights turn off	
FN+Spacebar	Reset	Long press 3s until light flashes, back to factory default

LED indicators; Caps lock: Green LED, Win lock: Green LED, Charging: Red, when charging is complete, the LED will turn off. To re-pair the keyboard with the 2.4GHz nano receiver, press and hold "Fn + Q(2.4G)" for 3 seconds until the keyboard backlight starts flashing quickly, the keyboard will connect automatically.

Provjerite jeste li uključili tipkovnicu pomoću "on/off" prekidača na stražnjoj strani tipkovnice prije korištenja.

Kombinacija tipki	Funkcija	Opis
FN+ESC	.	
FN+1	F1	
FN+2	F2	
FN+3	F3	
FN+4	F4	
FN+5	F5	
FN+6	F6	
FN+7	F7	
FN+8	F8	
FN+9	F9	
FN+0	F10	
FN+_	F11	
FN+=+	F12	
FN+backspace	DEL	
FN+CTRL_L	Mijenja ESC do += funkcije u " " , do F12	
FN+_	ESC	
FN+1	glazba	
FN+2	glasnoća -	
FN+3	glasnoća +	
FN+4	Nečujno	
FN+5	Stop	
FN+6	Prethodna pjesma	
FN+7	Reproduciraj/Pauza	
FN+8	Sljedeća pjesma	
FN+9	Email	
FN+0	Homepage	
FN+?	My computer	
FN+*+	Kalkulator	
FN+U	prtsc	
FN+I	scrik	
FN+O	pause	
FN+J	ins	
FN+K	home	
FN+L	pgup	
FN+M	del	
FN+;	end	
FN+:	pgdn	
FN+Y	Za Windows sisteme	
FN+X	Za MAC sisteme	
FN+TAB	Izmjena boje osvjjetljenja	U načinu jednog svjetla, ukupno 8 različitih boja za promjenu
FN+Zα	Izmjena efekta osvjjetljenja	Mjenjanje načina osvjjetljenja, 22 različita načina rada
FN+↓	Svjetlina -	0%-20%-40%-60%-80%-100%
FN+↑	Svjetlina +	0%-20%-40%-60%-80%-100%
FN+→	Sporiji efekt osvjjetljenja	
FN+←	Brži efekt osvjjetljenja	
FN+R	Prebaci na BT uređaj 1(BT3.0&5.0)	Kratko pritisnite, prijedite na BT, dugo pritisnite 3 s, izbrisite informacije o uparivanju i počinite spajati novi BT uređaj. LED dioda treptati će ako se odspoji, prestat će treperiti nakon spajanja.
FN+T	Prebaci na BT uređaj 2(BT3.0&5.0)	
FN+Z	Prebaci na BT uređaj 3(BT3.0&5.0)	
FN+Q	Prebaci na 2.4GHZ uređaj	Prvo treba uključiti nano prijemnik. Nakon toga dugo pritisnite 3 sekunde, kada je tipkovnica u statusu spajanja LED treperi, a nakon povezivanja treperenje prestaje.
FN+E	Prebaci na žičani način rada	
FN+WIN_L	Zaključavanje WIN tipke	Zaključavanje/otključavanje WIN i APP tipke
FN+ENTER	Gasi sva svjetla na tipkovnici	
FN+Spacebar	Reset	Zadržite 3 sekunde dok LED ne počne treptati - reset na tvorničke postavke

LED indikatori; Caps lock: Zeleni LED, Win lock: Zeleni LED, Punjenje: Crveno, kada se punjenje završi, LED će se ugasi. Za ponovno uparivanje tipkovnice s nano prijemnikom od 2,4 GHz pritisnite i držite "Fn + Q(2,4G) 3 sekunde dok pozadinsko osvjjetljenje tipkovnice ne počne brzo treperiti, tipkovnica će se automatski spojiti.