



**NUNCHAKKU**  
MECHANICAL RGB GAMING KEYBOARD

### User manual

#### Specifications and Features:

- \* Buttons: Compact 68 keys - Gradient keycaps
- \* Switches: Hot Swap dust-proof mechanical red
- \* Anti-ghosting: Full keys
- \* Polling rate: 1000 Hz
- \* Full key RGB LED backlight
- \* Dimensions: 310 mm x 101 mm x 42 mm
- \* Material: ABS plastic
- \* Key life: over 50 million times
- \* Weight: 550 g ±10g
- \* With extra 4pcs White Shark customized switches
- \* 60% ultra-compact layout
- \* Solid Type-C wired connection
- \* Hot-Swap dust-proof mechanical red switches for silent typing
- \* 18 LED effects with adjustable light brightness and running speed
- \* 1.8 m braided detachable cable
- \* Available software on [www.whiteshark.gg](http://www.whiteshark.gg)

EN-1

#### LED Indicator Description:

Caps Lock: white LED on Caps lock keycap  
 Windows Lock: white LED on windows keycap

#### FN combination function

1. Multimedia functions:  
 For example, if single press ESC, it's ESC;  
 if press FN + ESC, it's ~

If single press Q, it's Q;  
 if press FN+Q, it's My Computer

Single press	FN +	Single press	FN +	Single press	FN +
ESC	~`	Q	My Computer	::	Home
1	F1	W	Homepage	“”	End
2	F2	E	Email	,<	PRTSC
3	F3	R	Media player	.>	Scroll Lock
4	F4	T	previous track	/?	Pause
5	F5	Y	next track		
6	F6	U	Play/Pause		
7	F7	I	Stop		
8	F8	O	Volume +		
9	F9	P	Volume -		
0	F10	[{	Mute		
-_	F11	}]	Calculator		
=+	F12		N/A		

EN-2

#### 2. Combination function

FN +		remarks
INS	Switch backlight mode	18 light modes plus light off
DEL	Light color switch	Light effect cycle switching (red, orange, yellow, green, cyan, blue purple, white multicolor)
UP	Light brightness+	0%-25%-50%-75%-100%, and the indicator flashes 3 times when it is adjusted to the brightest.
DOWN	Light brightness-	100% -75% -50% -25% -0%, when adjusted to the darkest, the indicator light flashes for 3 times.
LEFT	Light speed +	There are 5 adjustable speeds in total. When the speed is adjusted to the slowest, the indicator light will flash for 3 times.
RIGHT	Light speed -	There are 5 adjustable speeds in total. When the fastest speed is adjusted, the indicator light will flash for 3 times.
PU	Light running from left to right	
PD	Light running from right to left	
WIN_L	WIN lock	White led indicator
SPACE	reset	FN+SPACE: Long press for 3 seconds to restore factory Settings, and backlight flashes three times

EN-3



**NUNCHAKKU**  
MECHANICAL RGB GAMING TIPKOVNICA

### Upute

#### Karakteristike i značajke:

- \* Broj tipki: Kompakt 68 tipki - Gradient tipke
- \* Prekidači: Izmjenjivi meh. crveni otporni na prašinu
- \* Anti-ghosting: Sve tipke
- \* Frekvencija uzorkovanja: 1000 Hz
- \* Pozadinsko osvjetljenje: RGB
- \* Dimenzije: 310 mm x 101 mm x 42 mm
- \* Materijal: ABS plastika
- \* Životni vijek tipki: preko 50 mil. pritisaka
- \* Težina: 550 g ±10g
- \* 4 dodatna White Shark switcha
- \* 60% ultra-kompakt layout
- \* Type-C sučelje
- \* Hot-Swap Mehanički crveni prekidači otporni na prašinu za tiho tipkanje
- \* 18 LED efekata s podesivom razinom jačine i brzinom izmjene efekta
- \* Odvojivi pleteni kabel od 1,8 m
- \* Softver dostupan na [www.whiteshark.gg](http://www.whiteshark.gg)

HR-1

#### Opis LED indikatora:

Caps Lock aktivan: bijeli LED svijetli na tipki Caps Lock  
 Zaključavanje Windows tipke: bijeli LED svijetli na tipki s Windows logom

#### Funkcije kombinacija s tipkom FN

1. Multimedia funkcije:  
 Na primjer, ako jednom pritisnete ESC, aktivira se tipka ESC  
 Ako pritisnete FN + ESC, dobit ćete znak ~

Ako jednom pritisnete Q, unosi se slovo Q  
 Ako pritisnete FN + Q, otvara se "My Computer"

Pritisak na tipku	FN +	Pritisak na tipku	FN +	Pritisak na tipku	FN +
ESC	~`	Q	My Computer	::	Home
1	F1	W	Početna stranica	“”	End
2	F2	E	Email	,<	PRTSC
3	F3	R	Media player	.>	Scroll Lock
4	F4	T	Prethodna pjesma	/?	Pauza
5	F5	Y	Sljedeća pjesma		
6	F6	U	Pokreni/Pauza		
7	F7	I	Stop		
8	F8	O	Pojačavanje		
9	F9	P	Stišavanje		
0	F10	[{	Nečujno		
-_	F11	}]	Kalkulator		
=+	F12		N/A		

HR-2

#### 2. Kombinacije tipki za kontrolu osvjetljenja

FN +		Napomene
INS	Prebacivanje načina pozadinskog osvjetljenja	18 načina osvjetljenja plus isključeno svjetlo
END	Prebacivanje boje svjetla	Izmjena svjetlosnih efekata (crvena, narančasta, žuta, zelena, cyan plava, bijela, višebojna)
UP	Povećanje svjetline +	0%-25%-50%-75%-100%, indikator zatreperi 3 puta kada je podešeno na najjače osvjetljenje
DOWN	Smanjenje svjetline -	100% -75% -50% -25% -0%, kada je podešeno na najtamnije, indikator zatreperi 3 puta
LEFT	Povećanje brzine svjetlosnih efekata +	Ukupno 5 podesivih brzina; kada je podešeno na najsporije, indikator zatreperi 3 puta
RIGHT	Smanjenje brzine svjetlosnih efekata -	Ukupno 5 podesivih brzina; kada je podešeno na najbrže, indikator zatreperi 3 puta
PU	Svjetlosni efekt – "trčanje" svjetla s lijeva na desno	
PD	Svjetlosni efekt – "trčanje" svjetla s desna na lijevo	
WIN_L	Zaklj. WIN tipke	Bijeli LED indikator
SPACE	reset	FN+SPACE: Dugi pritisak od 3 sekunde vraća tvorničke postavke; Pozadinsko svjetlo zatreperi tri puta

HR-3