



GK-2201 RONIN USER MANUAL / KORISNIČKE UPUTE



Features:

* Support 19 keys anti-ghosting:

(Q, A, Z, W, S, X, E, D, C, B, Space, ↑, ↓, ←, →, Tab, Alt-L/V, Ctrl_L/F, Shift_L)

* Fn+W Switch ASWD keys with ↑, ↓, ←, →

* Press FN+Win_L: Lock / unlock windows

* Press  : LED light on/off

Značajke:


* Podržava 19 tipki anti-ghosting:

(Q, A, Z, W, S, X, E, D, C, B, Razmaknica, ↑, ↓, ←, →, Tab, Alt-L/V, Ctrl_L/F, Shift_L)

* Fn+W zamjenjuje ASWD tipki s ↑, ↓, ←, →

* Pritisnite FN+Win_L: zaklj. / otklj. windows tipke

* Pritisnite  : LED osvjetljenje on/off

Fn keys / kombinacija tipki	Function / Opis funkcije	
	LED light breathing mode LED svjetlo breathing način	
	Adjust LED light breathing speed	
	Podešavanje brzine LED breathing (gašenja/paljenja)	
	Adjust LED light brightness	
	Podešavanje intenziteta LED svjetla	
Fn +	E	Media Player
	R	Volume- Glasnoća -
	T	Volume + Glasnoća +
	Y	Mute Stišano
	U	Pre Track Prethodna pjesma
	I	Play / Pause Play / Pauza
	O	Next Track Sljedeća pjesma
	P	Email Email
	[{	Web Web
	}]	Calculator Kalkulator
	ESC	~`
	1 !	F1
	2 @	F2
	3 #	F3
	4 \$	F4
	5 %	F5
	6 ^	F6
7 &	F7	
8 *	F8	
9 (F9	
0)	F10	
- _	F11	
= +	F12	
Home	Ins	
Del	End	
PgUp	PrtSc	
PgDn	Pause	